

Cleaning and maintenance procedure Laneway

The Laneway range incorporates a polyurethane (PUR) surface treatment, which protects the floorcoverings by resisting soiling. This protection facilitates the maintenance and provides the foundation for the ongoing low maintenance.

1. GENERAL INFORMATION

Well planned and regular maintenance, tailored to traffic conditions and frequencies, will help keep the floorcovering in pristine condition. Without regular maintenance, standards of appearance, hygiene and cleanliness, as well as the life expectancy of the floorcovering, will be compromised.

2. PREVENTATIVE MEASURES

In the initial stages of construction planning, attention should be paid to minimising the amount of dirt and water that can enter the building. To facilitate this, we strongly recommend the installation of passive dirt barrier systems in all entrance areas e.g. scraper and moisture mats. The mats should be positioned to ensure that access cannot be gained without walking on them, ideally, they should be at least four to six paces wide.

3. INITIAL CONSTRUCTION CLEAN

After laying, a final construction clean is to be carried out. All contamination and residue caused by construction and installation is to be completely removed here with a neutral pH detergent cleaner.

4. ROUTINE MAINTENANCE

Daily

Mop, sweep or vacuum the floor to remove dust and loose dirt. Stubborn marks should be removed using a neutral pH detergent cleanser and rinsed with water. After cleaning, if required, dry buff with a single-disc machine and a sky-blue 3M pad (approx. 1500 rpm)

Damp mop

Use a microfiber flat mop and neutral pH cleaner to remove dirt and stains. It is essential that the dirty detergent solution is then removed by rinsing the floor with water. A 2-step mopping system ensures the floor is clean from residue which can attract dirt, making the problem worse.

Spray Cleaning / Buffing

Wet buff the floor by using a rotary machine (approx. 175-400 rpm) and clean the floor, using 3M sharp shooter for spot cleaning prior to using the buffing machine. This will improve the appearance of the floorcovering. Use a clean 3M red pad.

5. PERIODICALLY

It may become necessary to remove stubborn marks from time to time by using a neutral or alkaline cleaner. Use according to the manufacturers' instructions. High speed (buffing/burnishing may be done with a 3M light blue pad at 1500-1800 rpm)

6. NOTE

Laneway can be treated with a metalized floor polish. This needs to be applied as per manufacturers' recommendations, and maintenance as above.

For further information please call Polyflor Customer Service on: Australia 1800 777 425